



## Garbage Disposal Replacement Unit Model GDR-A18

### Installation Instructions

- 1 Disconnect the power prior to removing the garbage disposal unit.**
- 2 Attach the 4 adjustable legs to the bottom of the housing.**
- 3 Secure the crown adaptor to the top of the housing through pre-drilled holes.**
- 4 Place the unit under the pre-rinse table. Raise the unit by adjusting the legs until firmly secured under the sink bowl.**
- 5 Connect one 2" outlet to the wall (or floor) drain with plumbing pipes, and seal off the unused outlet with the rubber cap provided.**